Recessed Mounting

1

Power Safety First

Turn Off Power: Ensure power is switched off before beginning the installation.

2

Ceiling Load Check

Verify Ceiling Support: Confirm the ceiling structure can handle the panel light's weight.

3

Prepare Ceiling Opening

Cut Mounting Slot: Create a groove/opening in the ceiling that matches the panel size. (Refer to Figure 1)



Electrical Wiring

Connect Wiring: Join power wires to the panel with proper insulation and sealing. (Refer to Figure 2)



Adjust Mounting Clips

Fold Spring Clips: Bend the four side clips to a 90° angle for insertion. (**Refer to Figure 3**)



Insert Panel

Secure into Ceiling: Push the panel into the cut-out to lock it in place. (Refer to Figure 4)




Figure 1




Figure 2




Figure 3




Figure 4

Suspended (Lifting) Mounting

Power Safety First

Turn Off Power: Disconnect power before installation.

Install Ceiling Fixers

Mount Suspension Anchors: Fix the suspension wire brackets to the ceiling. (Refer to Figure 5)

Attach Wires

3


Hang Suspension Wires: Connect the suspension wires to the ceiling fixers. (**Refer to Figure 6**)


Hook the Panel

Hang the Panel Light: Hook the LED panel onto the suspension wires. (Refer to Figure 7)

Power Connection

Connect and Insulate Wires: Link the power cable to the light and seal the joints for safety.





Backup Driver Installation (If Applicable)

Mount the Bracket

Install Fixture Bracket: Attach the mounting bracket to the back of the LED panel.

Attach the Driver

Secure Backup Driver: Mount the driver unit onto the rear bracket.

Wire the Driver

Connect Backup Driver: Route the driver's wiring through the compartment and follow the wiring diagram for correct connections.

